



Vanagon Westfalia Pop Top Tent Replacement

A step by step video tutorial on how to change the screw-in 1985-1991 Vanagon Westfalia pop top tent.

Written By: eCuration



INTRODUCTION

An instructional video for installing a pop-top tent on a Vanagon (1985-1991). This video gives you everything you need to know in order to install the screw-in style tent.

Not to be confused with the staple in type found on the earlier 1980-1985 Westfalia. If you are unsure of which style you have, the screw-in style will have metal rails attaching the tent at the top.

This repair is best done with a friend or two as it is recommended that the fiberglass top is removed from the vehicle.

[video: <https://www.youtube.com/watch?v=ASC9dZkfxbQ>]



TOOLS:

- [10mm Wrench](#) (1)
 - [10" Ratchet Extension](#) (1)
 - [10mm Socket](#) (1)
 - [3/8" Drive Ratchet](#) (1)
 - [Razor Blade](#) (1)
 - [Sawhorse Folding Stands](#) (1)
 - [Cordless Drill](#) (1)
-

Make sure to keep the new tent clean and dry as this will allow it to last for years.

This document was last generated on 2017-10-04 11:01:42 AM.